



Universal Coatings (Pty) Ltd | Reg No: 1982/10922/07

UNIVERSAL ALLWOOD
ACRYLIC EMULSION
PRODUCT CODE
TECHNICAL DATA SHEET
November 2016.R3

<ul style="list-style-type: none"> • Product Description 	<ul style="list-style-type: none"> • Universal Allwood Suede or Gloss is manufactured using low viscosity long oils blended with selected linseed oils and UV absorbers. • Does not contain wax in any form. 						
<ul style="list-style-type: none"> • Application Areas 	<ul style="list-style-type: none"> • Suitable for exterior or interior wooden window frames, doors and frames, skirting's and garden furniture. 						
<ul style="list-style-type: none"> • Product Features 	<ul style="list-style-type: none"> • High durable and UV resistant (recommended 3 coat application on suitably prepared wood substrates). 						
<ul style="list-style-type: none"> • Product Data 	<table border="1"> <tr> <td>Resin Base</td> <td>Alkyd Resin.</td> </tr> <tr> <td>Drying Time</td> <td>± 4-6 hours</td> </tr> <tr> <td>Film Thickness</td> <td>25 – 35 microns.</td> </tr> </table>	Resin Base	Alkyd Resin.	Drying Time	± 4-6 hours	Film Thickness	25 – 35 microns.
Resin Base	Alkyd Resin.						
Drying Time	± 4-6 hours						
Film Thickness	25 – 35 microns.						
<ul style="list-style-type: none"> • Surface Preparation 	<ul style="list-style-type: none"> • Clean, firm and dry. 						
<ul style="list-style-type: none"> • New Wood 	<ul style="list-style-type: none"> • Sand in direction of grain. Start with 100 – 150 grit paper and finish with 230 – 280 grit paper for a smooth finish. 						
<ul style="list-style-type: none"> • Previously varnished Wood in good condition 	<ul style="list-style-type: none"> • Sand to matt and even finish with 150 grit paper and remove all dust. 						
<ul style="list-style-type: none"> • Previously varnished Wood in bad condition 	<ul style="list-style-type: none"> • Sand as per “New Wood” instructions or remove old varnish with paint stripper then sand as per “New Wood” instructions. 						
<ul style="list-style-type: none"> • Wood previously coated with wood treatments containing oil and wax 	<ul style="list-style-type: none"> • Clean oiled wood with Universal Mineral Turpentine or paint stripper, allow to dry and prepare as per “New Wood” 						
<ul style="list-style-type: none"> • Cleaning 	<ul style="list-style-type: none"> • Clean-up with Universal Mineral Turpentine. 						
<ul style="list-style-type: none"> • Precautions 	<ul style="list-style-type: none"> • Keep out of reach of children, flames or sparks. • Ensure good ventilation during application and drying. 						
<ul style="list-style-type: none"> • Disclaimer 	<p>Universal Paints cannot be held liable if the product fails due to improper surface preparation or application.</p>						
<p>Universal Coatings (PTY) LTD Reg No. 1982/10922/07</p>							
<p>19 Staal Street Kya Sands, Randburg South Africa</p>	<p>Tel. +(27) 11- 462 4284 www.universalphaints.co.za</p>						